

DESCRIPTION

LiquiTec is an extremely low odor, fluid-applied waterproofing system designed to maintain, restore and upgrade the performance of aged modified bitumen, metal and single-ply roof systems. This two-component, 100% solids, aliphatic polyurea cures quickly to form a highly durable, impact and UV resistant roof membrane that increases the life span of the existing roof.

MATERIALS

The materials used in the LiquiTec single-ply restoration system include:

1. Coating: LiquiTec Base, LiquiTec
2. Primer: Rust-Go Primer (for priming metal components only)
3. Fabric Reinforcement: Ulti-Mat™, Grip Polyester™ Firm, Grip Polyester™ Soft or UniBond ST™
4. Cleaning Solution: Garland D7 or Simple Green® Oxy Solve

APPLICATION EQUIPMENT

1. 3/8" (10 mm) shed resistant nap roller
2. Heavy duty electric power drill (cordless drills are not permitted)
3. Jiffy mixer blade (ES model)

INSTALLATION

Installation of the LiquiTec system is accomplished in the following steps: repair, preparation, mixing, and application.

Prior to installation, ensure that adhesion testing was conducted in accordance with Garland adhesion testing procedures to verify a minimum adhesion strength of four (4) pounds per linear inch (pli) for LiquiTec to the applicable substrates. When calculating material requirements for a particular project, consideration must be given to applicator variance and surface texture. Any of the LiquiTec coatings may be used interchangeably as base or top coating layers. Best practice is to use a different coating color for each subsequent layer of coating (e.g. gray & white).

Repair

1. All necessary field and flashing repairs must be done according to good construction practices, including the removal of all wet insulation and defective materials as identified through a moisture detection survey such as an infrared scan and replacement with like materials.
2. All single-ply seams must be checked and any loose seams must be resealed, or if necessary, replaced with new single-ply material.
3. Significantly wrinkled single-ply membrane areas must be cut out and replaced to ensure a smooth substrate.
4. Repair any single-ply membrane that has shrunk and is tenting at walls.
5. Remove any walkway pads and make necessary repair with new single-ply membrane.
6. All roof areas must promote positive drainage.

Preparation

1. Confirm local water run-off ordinances and restrictions prior to cleaning roof.
2. Carefully power wash all roof surfaces with greater than 2,000 psi pressure to remove debris, rust, scale, dirt, dust, chalking, peeling or flaking coatings, etc. Do not force water into the roof system or damage roof surfaces.

3. Wearing personal protective clothing and equipment, remove algae, mildew or fungus with Garland D7 or Simple Green® Oxy Solve and scrubbing with a push broom scrub brush. Rinse at least twice to be sure all cleaning agents or contaminants are completely removed to prevent adhesion issues.
4. If the roof surface becomes contaminated with dirt, dust or other particles at any time during the application of the LiquiTec system, cleaning measures must be taken to restore the surface to a suitable condition.
5. Ensure roof is dry prior to application

Mixing Procedure

1. Open LiquiTec container.
2. Remove Part B jug and its plastic holding compartment out of the pail.
3. Mix Part A liquid for one minute using an electric heavy-duty power drill and Jiffy mixer blade (ES model). Cordless drills are not permitted as they will not properly mix the materials.
4. While mixing, slowly pour contents of Part B jug into the Part A pail. Mix the two components together for two minutes, moving the Jiffy blade from top to bottom and along the sides to ensure the product is thoroughly mixed.

Always mix entire kit contents together as packaged. Do not break down into smaller quantities.

Note: Mixed product pot life is 25-35 minutes depending on ambient temperature. Rising temperatures may reduce pot life and lower the product's viscosity at a faster rate than desired. Lower product viscosity will increase flow rate making it more difficult to apply the coating at the specified coverage rate and fully saturate any fabric reinforcement.

Application Of Standard LiquiTec Single-Ply Restoration System

Single-Ply Membrane field/flashing seams and details coating

1. Apply LiquiTec Base or LiquiTec coating 8 in. (200 mm) wide over all seams. Always begin with flashing seams and details before proceeding to field application. The minimum application rate should be 2.0 gal./100 sq. ft. (0.82 l/m²). Care should be taken to apply the coating without air pockets, puddles or pinholes.
2. Allow to cure thoroughly before applying field coating layers.

Note: Fabric reinforcement is only required in areas that hold water, around drains, on loose/damaged seams or over existing membrane repairs. Recommended over originally adhered single-ply seams. Choose fabric reinforcement Method 1 or 2 indicated in the Partially Reinforced System below.

Application Of Partially Reinforced LiquiTec Single-Ply Restoration System

Single-Ply Field/Flashing Side Laps, End Laps and Details (Choose Method 1 or 2)

Method 1: Application of UniBond ST

1. Always begin with flashing seams and details.
2. Verify the surface is clean and properly prepared.
3. Round corner edges of UniBond ST with scissors.
4. Remove the clear release liner from the back in workable sections.
5. Center 6" wide UniBond ST over the middle of lap. For other details requiring reinforcement such as drains, penetrations and curbs, 12" wide UniBond ST is available.

6. Use care to install the tape uniformly. Do not stretch or cause air pockets, wrinkles or fishmouths.
7. Apply pressure to tape starting at the center and work toward outside edge with a steel roller to activate the bonding process.
8. Inspect the tape to ensure it is properly installed. Verify edges are tightly fixed to surface. If any discrepancies are present, repair before the coating is applied.
9. Saturate the tape's polyester surface with LiquiTec coating and allow to cure before applying field coating.

Method 2: Application of Three-Course LiquiTec

1. Always begin with flashing seams and details
2. Determine where the first run of 6 in. (150 mm) wide Ulti-Mat fiberglass or Grip Polyester Soft reinforcement will be started and verify the surface is clean. For other details requiring reinforcement such as drains, penetrations or curbs, 12", 38" and 40" wide fabric reinforcement is available.
3. Position Ulti-Mat fiberglass or Grip Polyester Soft to roll out, apply coating at 3.0 gal./100 sq. ft. (1.22 l/m²) extending 4 in. (100mm) on each side of lap to where the reinforcement is to be applied. Immediately roll reinforcement into the coating and completely saturate surface, ensuring full encapsulation of fabric without pinholes, voids, openings or vertical fibers.
4. Allow to cure before applying field coating.

Single-Ply Field Coating

1. Prior to field coating application, the local Garland Representative needs to complete an inspection of all treated seams and details.
2. Apply a base coating of LiquiTec Base or LiquiTec coating in a uniform manner at minimum application rate of 1.5 gal. /100 sq. ft. (0.61 l/m²) over the entire roof surface, including all flashings. Use a ¼" notched squeegee to spread coating and roller apply for uniform minimum coverage. Allow to cure thoroughly, but no more than 72 hours.
3. Apply a top coating of LiquiTec Base or LiquiTec coating in a perpendicular direction over the base coat at 1.0 gal./100 sq. ft. (0.41 l/m²)

Application Of Fully Reinforced Single-Ply System

1. Fully reinforced system does not require fabric reinforcement pre-treatment of single-ply seams.
2. Start with drains and flashings, including walls and curbs before proceeding to field installation. Apply a base coating of LiquiTec Base or LiquiTec coating at 3.0 gal./100 sq. ft. (1.22 l/m²) over single-ply roof surface. Use a ¼" notched squeegee, where applicable, to spread coating and roller apply for uniform minimum coverage.
3. Immediately embed 38" wide Ulti-Mat fiberglass or 40" wide Grip Polyester Firm or Soft reinforcement into wet coating by rolling over the fabric surface to fully saturate and encapsulate, ensuring no wrinkles, voids or vertical fibers.

4. Lap rolls of reinforcement 3 in. (75 mm) on end and side laps. Roller must be fully saturated with coating when backrolling over the reinforcement surface to wet it out completely. Allow to cure thoroughly, but no more than 72 hours.
5. Apply a top coating of LiquiTec Base or LiquiTec Coating over the base coat at 2.0 gal./100 sq. ft. (0.82 l/m²).

Application Of Non-Skid Surface For Walkways

1. Apply LiquiTec Base or LiquiTec coating at 1.0 gal./100 sq. ft. (0.41 l/m²) to clean and dry topcoat within 72 hours of its application.
2. Broadcast dry roofing granules or 20-40 mesh silica sand at 30 lbs./sq. into wet coating and immediately back-roll to set.

INSPECTION

Inspect entire roof area and touch-up deficient areas with additional LiquiTec as necessary to ensure complete and uniform coverage. Solvent wipe coating with acetone or MEK if it is exposed over 72 hours prior to overcoating. Special attention should be given to critical areas of roof, including roof penetrations, transitions, existing membrane seams, flashings and drains.

LIMITATIONS

These are general guidelines for application of the LiquiTec system. The material requirements may vary depending on the specific job requirements. If unusual conditions exist, contact your local Garland Representative. Garland's fluid-applied elastomeric roof systems must be applied to structurally sound substrates and properly prepared surfaces. All surfaces must be clean and dry before application of coatings. Garland's roof systems must not be applied over wet insulation or roofing materials. Failure of the substrate does not constitute failure of the Garland coating or system. Garland's systems are designed for use on roofs with positive drainage.

1. Product application must not be done when rain or other conditions such as fog or heavy dew are possible within a 24-hour period.
2. Roof surface must be at least six Fahrenheit degrees or three Celsius degrees above the dew point and rising.
3. Surfaces must always be clean before application of product. Care must be taken to ensure that on-site manufacturing emissions or extended time intervals after original cleaning does not interfere with any stage of the coating applications. If either condition occurs, then cleaning may be required again.
4. Drying time is affected by numerous factors, including temperature, direct sunlight, relative humidity, air movement, thickness, etc. Coating skin time is between 3-4 hours and overcoat time is 6 hours at 77°F (25° C) and 50% relative humidity. Higher temperature and/or humidity will result in reduced skin and overcoat times; lower temperature and/or humidity may extend skin and overcoat times.
5. Thinning of coating materials is not permitted.

6. Adequate coating thickness is essential to performance. A controllable area should be measured and the specified material applied. The minimum coverage rate must be achieved throughout the entire fluid-applied roofing assembly and must be verified using a wet mil gauge during application. Multiple coats may be necessary on verticals to prevent sagging.
7. Solvent wipe coating with acetone or MEK if it is exposed over 72 hours prior to overcoating.
8. If new single-ply membrane is used for repairs, it must be solvent-wiped with acetone prior to coating.
9. Deviations from these application guidelines and specific material requirements may seriously affect the fluid-applied roofing system performance and are strictly prohibited.
10. Applicator must comply with all applicable local, state and federal regulations if lead-based paint or other hazardous materials are encountered.
11. Roofing is hazardous work and coatings are very slippery when wet. Comply with fall protection rules and regulations.
12. Do not spray

COLD WEATHER RESTRICTIONS

Do not attempt application if ice, snow, moisture or dew is present. Bonding substrates must be clean, dry and free of dust or other inhibitors of proper adhesion. Ambient temperature must be 50°F (10°C) and rising through the day. Restrict application when overnight temperature drops below 40°F (4.4°C). Cooler temperatures will negatively impact the properties of the system. Contact your Garland Sales Representative for proper cold weather applications.

HOT WEATHER RESTRICTIONS

Do not attempt application if moisture or dew is present. Ambient temperature must be less than 95°F (35°C). Contact Garland Sales Representative for proper hot weather application.

STORAGE

LiquiTec on the job site should be stored in a shaded ventilated area under a light-colored reflective tarp. Do not store in direct sunlight. Storage temperature should range from 60-80°F (15°C to 26°C). Indoor ventilated storage is recommended when ambient temperature is below 60 °F (15 °C) or above 80 °F (26 °C).

For more information, visit us at: www.garlandco.com

The Garland Company, Inc.
Toll Free: 800-321-9336

Garland Canada Inc.
Toll Free: 800-387-5991

All products listed are trademarks of The Garland Company, Inc. unless otherwise noted.
Simple Green is a trademark of Sunshine Maker's, Inc.
© 2021 Garland Industries, Inc.